




Select your Otto




Select your Otto Com PORT




If your Otto's com port is shown, then **CLICK** on the **OPEN PORT** button.




If no com port is displayed or it is incorrect, or if you need to change the **BAUD RATE** from its default 9600 then click on the **AUTO** tick box



Select your Com port and **BAUD RATE**, click **CLOSE** when finished, Then click on the **OPEN PORT** button



Use any of the functions that are available, different versions of Otto have different functionality.



CLICK on the function requested, this will place it in on the screen

With your LEFT mouse click, drag to the DANCE position you would like , the image will 'SNAP' to that position, click on the X to delete if needed

Select the number of times this step is to be repeated with the + and - buttons

When ready CLICK on the PLAY, any dance steps with nothing selected will be skipped, REMEMBER you can select GETSURES, SOUNDS, BASIC MOVES